

REBEL TANK
REFILLING E-LIQUID

1. Turn the tank upside-down and unscrew the steel base.
2. Point and pour e-liquid into the sides of the tank. Fill to about 75% capacity of the tank. (DO NOT OVER-FILL OR POUR E-LIQUID INSIDE OF THE CENTER TUBE)
3. Screw the steel base back onto the tank.

AIR FLOW CONTROL TECHNOLOGY

Turn the Air Flow Control clockwise to increase airflow and counterclockwise to decrease airflow.



REBEL TANK

CHANGING YOUR ATOMIZER HEAD

Once you experience a burnt taste, a decrease in flavor or vapor production, it may be time to replace your atomizer head. It is recommended to change your atomizer head once every 1-4 weeks (depending on use).

To get the truest flavor from your e-liquid, we also suggest changing your atomizer head when switching e-liquid flavors.

1. To replace the atomizer head, turn your tank upside-down and unscrew and remove the steel base by turning it counterclockwise.
2. While still holding onto the steel base, grip the top of the atomizer head and unscrew it counterclockwise to remove the atomizer head from the steel base.
3. Once the old atomizer has been removed, screw in a new atomizer head by turning it clockwise into the steel base until you feel resistance. Make sure not to over tighten the atomizer head as this may damage the rubber O-rings and cause leakage.
4. Screw the steel base back onto your tank by turning it clockwise. Make sure not to over tighten.
5. Prime your atomizer by taking a few “dry puffs” without pressing the power button in order to saturate the wick.



USER MANUAL
ESPAÑOL

REBEL TANQUE RECARGAR EL E-LÍQUIDO

1. Ponga el tanque hacia abajo y desenrosque la tapa de acero.
2. Apunte y vierta el e-líquido a los lados del tanque. Llene hasta aproximadamente el 75% de capacidad del tanque. (NO LO LLENE DEMASIADO NI VIERTA EL E-LÍQUIDO DENTRO DEL TUBO CENTRAL).

TECNOLOGÍA PARA EL CONTROL DEL FLUJO DE AIRE

Gire el control del flujo de aire en el sentido de las agujas del reloj para aumentar el flujo de aire y en sentido contrario de las agujas del reloj para disminuir el flujo de aire.



CÓMO CAMBIAR EL CABEZAL DE SU ATOMIZADOR

Cuando sienta un sabor a quemado, una disminución en el sabor o la producción de vapor, puede ser momento de reemplazar el cabezal de su atomizador. Se recomienda cambiar el cabezal de su atomizador una vez cada 1 a 4 semanas (dependiendo del uso).

A fin de obtener el sabor más auténtico del e-líquido, también sugerimos cambiar el cabezal de su atomizador cuando cambie los sabores del e-líquido.

1. Para reemplazar el cabezal del atomizador, ponga su tanque hacia abajo, desenrosque y retire la base de acero girándola en sentido contrario a las agujas del reloj.
2. Mientras aún sostiene la base de acero, sujete la parte superior del cabezal del atomizador y desenrósqelo en sentido contrario a las agujas del reloj para retirarlo de la base de acero.
3. Una vez que haya retirado el atomizador usado, enrosque un nuevo cabezal de atomizador girándolo en el sentido de las agujas del reloj en la base de acero hasta que sienta resistencia. Asegúrese de no ajustar demasiado el cabezal del atomizador ya que esto puede dañar las juntas de goma y ocasionar fugas.
4. Enrosque la base de acero de nuevo en su tanque girándola en el sentido de las agujas del reloj. Asegúrese de no ajustarla demasiado.
5. Prepare el atomizador tomando algunos “golpes secos” sin presionar el botón de encendido y deje que su tanque repose unos minutos para saturar la mecha.