


## TANK

## REFILLING E-LIQUID

When you have about 25% of e-liquid remaining or you experience a slightly burnt taste, you will need to refill your tank with e-liquid.

1. Always remove the battery from the tank before refilling with e-liquid.
2. Unscrew and remove the mouthpiece in order to fill the tank.

3. Point and pour e-liquid into the sides of the tank. Fill to about 75% capacity of the tank. (DO NOT OVER-FILL OR POUR E-LIQUID INSIDE OF THE CENTER TUBE)
4. Screw the mouthpiece back onto the tank.



## TANK

## CLEAR TANK

Once you experience a burnt taste, a decrease in flavor or vapor production, it may be time to replace your atomizer. It is recommended to change your atomizer head once every 1-4 weeks.

To get the truest flavor from your e-liquid, we also suggest changing your atomizer head when switching e-liquid flavors.

1. Before replacing your atomizer head, make sure your tank does not contain any e-liquid.
2. To replace your atomizer head, unscrew and remove your tank's mouthpiece by unscrewing the mouthpiece counterclockwise.
3. Grip the top of the atomizer head, located in the center of the tank, and unscrew the atomizer counterclockwise.
4. Once the old atomizer has been removed, screw in a new atomizer head by turning it clockwise into the center of your tank. **Make sure not to over tighten the atomizer head as**

**this may damage the rubber O-rings and cause leakage.**

5. Screw on the mouthpiece.


## TANQUE

### RECARGAR EL E-LÍQUIDO

Cuando le quede aproximadamente 25% del e-líquido en el tanque o siente un sabor ligeramente quemado, tendrá que volver a llenar su tanque de e-líquido.

1. Siempre retire la batería del tanque antes de recargarlo con el e-líquido.
2. Destornillar y retire la boquilla para llenar el tanque.

3. Apunte y vierta el e-líquido a los lados del tanque. Llene hasta aproximadamente el 75% de capacidad del tanque. (NO LO LLENE DEMASIADO NI VIERTA EL E-LÍQUIDO DENTRO DEL TUBO CENTRAL).
4. Atornille la boquilla de nuevo en el tanque.



## TANQUE

### TANQUE CLEAR

Cuando sienta un sabor a quemado, una disminución en el sabor o la producción de vapor, puede ser momento de reemplazar su atomizador. Se recomienda cambiar el cabezal de su atomizador una vez cada 1 a 4 semanas.

A fin de obtener el sabor más auténtico del e-líquido, también sugerimos cambiar el cabezal de su atomizador cuando cambie los sabores del e-líquido.

1. Antes de reemplazar el cabezal de su atomizador, asegúrese de que su tanque no contenga e-líquido.
2. Para reemplazar el cabezal de su atomizador, desenrosque y retire la boquilla de su tanque girándola en sentido contrario a las agujas del reloj.
3. Sujete la parte superior del cabezal del atomizador, ubicado en el centro del tanque, y desenrosque el atomizador en sentido contrario a las agujas del reloj.
4. Una vez que haya retirado el atomizador

usado, enrosque un nuevo cabezal de atomizador girándolo en el sentido de las agujas del reloj en el centro de su tanque. **Asegúrese de no ajustar demasiado el cabezal del atomizador ya que esto puede dañar las juntas de goma y ocasionar fugas.**

5. Enrosque la boquilla.