



VIPER

ENGLISH

## VIPER TANK QUICK START GUIDE

### WHAT'S INCLUDED

- 1x Viper Tank
- 1x 316L 0.2ohm Atomizer (Pre-Installed)
- 1x 0.5ohm Atomizer
- 1x User Guide

### ATOMIZER HEAD PRIMING

When getting ready to use the provided 0.2ohm atomizer, it is important that you prime the atomizer to avoid a burnt hit. This can be a very cost saving measure. Unscrew the base

of the tank from the tank's body and remove the atomizer by unscrewing it from the base. You will next take your e-liquid of choice and drop 3-5 drops into the center of the atomizer. Do not exceed 5 drops to avoid flooding the atomizer. Once you have completed this task, screw atomizer back into the base, then proceed to screw base into the body of the tank. You are now ready to fill your tank with your e-liquid.

### TANK FILL PROCESS

The Viper offers a unique juice flow feature that allows users to control the juice intake of its atomizer. Please note that the juice flow control ring, as well as the airflow control ring, must be closed each time the tank is being filled to avoid leaking. Once both controls are closed, unscrew

the top cap of your tank, take your liquid and proceed to pour your liquid into one of the two slots around the center air pipe. After filling tank, screw the top cap back onto the body of the tank. Next, reopen both the juice airflow controls. Lastly, using short breaths, inhale from the drip tip up to 5 times and allow tank to sit for at least 10 minutes to give the atomizer time to soak in your liquid.

**NOTE:** Do not overfill, avoid liquid going above the opening of the center air pipe.





ESPAÑOL

## GUIA DE INICIO DE TANQUE VIPER

### QUE VIENE INCLUIDO

- 1x Tanque Viper
- 1x 316L Atomizador de 0,2ohm
- 1x Atomizador de 0,5ohm
- 1x Manual de Usuario

### CEBADO DE LA CABEZA DEL ATOMIZADOR

Cuando esté pronto para utilizar el atomizador de 0,2 ohm provisto, es importante cebar el atomizador para evitar quemaduras. Esta puede ser una medida que ahorre muchos costos.

Desatornille la base del tanque del cuerpo del mismo y retire el atomizador desenroscándolo de la base. A continuación tome su "e-líquid" elegido y deje caer 3-5 gotas en el centro del atomizador. Para evitar inundar el atomizador, no exceda las 5 gotas. Una vez haya completado esta tarea, atornille el atomizador de nuevo en la base y proceda a atornillar la base en el cuerpo del tanque. Ahora está listo para llenar el depósito con el e-líquido.

### PROCESO DE LLENADO DEL TANQUE

El Viper ofrece una función de flujo de líquido única que permite a los usuarios controlar la ingesta de líquido en su atomizador. Tenga en cuenta que el anillo de control de flujo de

líquido, así como el anillo de control de flujo de aire, se deben cerrar cada vez que el tanque esté siendo llenado para evitar fugas. Una vez que ambos controles están cerrados, desenrosque la tapa de su tanque, tome su líquido y proceda

a verterlo en una de las dos ranuras alrededor del tubo de aire del centro. Después de llenar el tanque, atornille la tapa de nuevo, en el cuerpo del tanque. A continuación, vuelva a abrir tanto los controles de flujo de aire como los de líquido. Por último, con respiraciones cortas, inhale desde la punta de goteo hasta 5 veces y permita que el tanque repose por al menos 10 minutos para darle tiempo al atomizador para sumergirse en su líquido.

